

## **FOR HPT770 PLOTTER AND T3500 CATEGORY USAGE**

- 1. Menu**
- 2. Internal Prints**
- 3. User Information Prints**
- 4. Print Usage Report**

## **FOR T730/T830 PLOTTER**

- 1. Touch gear icon**
- 2. Scroll down to Reports**
- 3. Select Printer Status Report**

## **FOR T795, T1300 & T2300 PLOTTER**

- 1. Touch (i) for information**
- 2. Go to wrench**
- 3. Scroll down to Internal Prints**
- 4. Touch User Info Prints**
- 5. Print Usage Report**

## **FOR T2500 PLOTTER**

- 1. Press double gear icon**
- 2. Press single gear icon**
- 3. Press Internal prints**
- 4. Press User information prints**
- 5. Press Print usage report**

## **FOR T3500 PLOTTER**

- 1. At Main Screen, swipe to left**
- 2. Meter will display on Screen**
- 3. Send Area/ Square Foot Reading and ink usage**

**Please send usage report to Cathy Ledford @ 704-333-3849 or email to [cathy.ledford@duncan-parnell.com](mailto:cathy.ledford@duncan-parnell.com)**