

TCS500 Directions: Press Online/Offline key to enter offline mode. Select next until “Display Counters” appears on screen. Select Display Counter and Press Finish to return to Offline Screen.

Plotwave 340/360 Directions: Touch Gear at top right of User Interface. Reading needed is Area Counter.